


The air-piloted, **pressure-balancing glue regulator** is used with Valco Cincinnati's variable-speed flow controls. The regulator relieves glue pressure during production stops to prevent pattern flooding as production resumes.


The air pressure-to-glue pressure ratio is approximately 1:1. A 3:1 & 6:1 ratio assembly is also available. The assemblies include a three-way shutoff valve and air pressure regulator that allow operators to bypass the flow control for system purge and testing.




Pressure-Balancing Glue Regulator

for use with variable-speed flow controls (1:1 ratio)

DS066



When used with EPC, the glue pressure decreases as the machine speed decreases. When the machine is stopped, the glue pressure is relieved from the hose connected to the valve. If the valve needs to be purged or fired while the machine is stopped, air must be supplied to the dome of the regulator by a separate air line.



Bowl Assembly (see drawing above)

Bowl Assembly, NPT	593xx411
Bowl Assembly, BSPP	593xx410
1 Bottom Plug	593xx297
2 O-ring	745xx080
6 Ball/Seat Check Cartridge, Viton	593xx538
7A Regulator Housing, NPT	593xx350
7B Regulator Housing, BSPP	593xx351
8 Activator Pin	593xx262
9A Pipe Plug, NPT	799xx039
9B Pipe Plug, BSPP	799xx690

Glue Regulator Assemblies (see drawing on front)

Glue Regulator, 1:1 ratio, 0–160 psi, NPT	593xx408
Glue Regulator, 1:1 ratio, 0–12 bar, BSPP	593xx413
1A Bowl Assy	593xx411
1B Bowl Assy, Metric	593xx410
2A Gauge and Protector Assy.	786xx066
2B Gauge HP	786xx001
3 Cylinder	593xx415
4 Cap	593xx414
5 Piston	593xx412
6 Bracket	593xx416
7 3-way Ball Valve	704xx745
8 Nipple	797xx089
9 Street Elbow	797xx007
10A Reducer	792xx330
10B Adapter	792xx135
11 Regulator, Air	594xx114
12 Gauge	786xx001
15 Screw	784xx595
16 Screw	798xx296
17 Screw	784xx426
18 Hex Nut	798xx416
19 Flat Washer	784xx183
21 Diaphragm	746xx114
22 Label	781xx817
23 Adhesive Transfer Tape	781xx818
24 Tubing	755xx528
26 Label	794xx917
27 Washer	793xx470
29 Elbow, 90 degree	799xx821
30 8mm “Y” Fitting	799xx678
31 Tube End Expander	799xx478

Rebuild Kit

Rebuild kit for 1:1 Regulator Assembly, EP	593xx530
Rebuild kit for 1:1 Regulator Assembly, Viton	593xx418
1 Rolling Diaphragm	746xx114
2 Tape, adhesive transfer	781xx821
3 Fixture, rebuild kit	593xx417
4 O-ring*	746xx163
O-ring**	745xx080
8 Ball/Seat Check Cartridge, epdm seals*	593xx539
Ball/Seat Check Cartridge, Viton**	593xx538
9 Male Quick Disconnect	752xx004
10 Bushing Reducer 1/2 x 1/4	797xx049
11 Hex head pipe plug 1/2	797xx040
12 Activator pin, regulator	593xx262
13 Instruction Sheet 1:1 prop reg	ISO291

*Included in EP kits.

**Included in Viton kits

BALANCING PROPORTIONAL REGULATOR REPAIR

7/2020

IS0291

1:1 Balancing Proportional Regulator

Disassembly procedure

1. Relieve pressure from the air and glue lines.
2. Remove the M5 x 90 Socket Head Cap Screws.



The ball valve may need to be rotated to provide access to the screws.

3. Remove the cap from the regulator assembly.

CAUTION!


When removing the cap, be sure the diaphragm is not stuck to it.



4. Remove the cylinder assembly from the bowl assembly.


CAUTION!

Be sure the diaphragm is not stuck to the bowl assembly.




Repair Kit (EP - 593xx530; Viton - 593XX418)

ITEM	DESCRIPTION	PART NUMBER	EP	VITON	QTY
1	ROLLING DIAPHRAGM	746XX114			2
2	TAPE, ADHESIVE TRANSFER	781XX821			1
3	FIXTURE, REBUILD KIT	593XX417			1
4	O-RING	746XX163	x		1
		745XX080		x	1
8	BALL SEAT ASSEMBLY	593XX539	x		1
		593XX538		x	1
9	MALE QUICK DISCONNECT	752XX004			1
10	BUSHING REDUCER 1/2 X 1/4	797XX049			1
11	HEX HEAD PIPE PLUG 1/2	797XX040			1
12	ACTIVATOR PIN; REGULATOR	593XX262			1
13	INSTRUCTION SHEET 1:1 PROP REG	IS0291			1


Bowl Assembly Repair

Diaphragm Repair


1. Remove the release liner from one side of the transfer tape.
2. Place the cylinder and piston on the transfer tape.
3. Flip the assembly over and hold the piston in place.
4. Punch holes for the screws.
5. Cut the tape around the outside and inside of the cylinder.
6. Cut the tape around the outside of the piston.
7. Repeat for the other side of the piston assembly.




There should now be a piece of transfer tape on either side of the piston, and a piece of transfer tape (with matching holes) on either side of the cylinder, as shown in exploded view, below.




8. Fold back part of the transfer tape release liner on one side of the piston.
9. Remove the release liner from the other side.



10. Remove the tape release liner from one side of the cylinder.




11. Insert the diaphragm into cylinder, so the flange contacts the adhesive surface.

**CAUTION!**

Be sure to align the mounting holes.


12. Insert the piston into the cylinder with the adhesive side down.
13. Place the assembly on a flat surface with the diaphragm face down.




14. Push the piston down into the cylinder.




The piston should be pushed down until it bottoms out. Air pressure from the bottom will 'form' the diaphragm.




15. Place the rebuild fixture (Item 3) underneath the cylinder.




16. Push the piston down through the rebuild fixture until it bottoms out.




17. Remove the tape liner from the top surface of the piston.



18. Remove the tape liner from the top of the cylinder.



19. Insert the diaphragm into the cylinder so the flange contacts the adhesive.




CAUTION!



Be sure to align the holes.


20. Push the diaphragm down.

21. Flip the assembly over and place the rebuild fixture on the bottom.



22. Push on the diaphragm, gently, to move the piston through the rebuild fixture until it bottoms out.

Reassembly Procedure



1. Place the cylinder on the bowl assembly. Be sure the screw holes are aligned.
2. Place cap on top of cylinder.

CAUTION! Be sure the screw holes are aligned.




3. Use a wire brush to clean the remains of thread locker from the screw threads.
4. Apply a liberal amount of blue, medium-strength thread locker (710XX620) to the threads of the M5 x 90 Socket Head Cap Screws.

5. Tighten the screws to 30 in.-lbs.

CAUTION! Over-torqueing can damage the diaphragm.



Test Procedure



1. Attach items 9, 10, and 11 to the bowl regulator, as shown below.
2. Attach shop air to item 9 and to the manual air-inlet fitting.

 Leave the air tube off of the automatic air-inlet fitting.
3. Use the air regulator to regulate pressure to 80 PSI.
4. Check for air leaks around the diaphragm.
5. Turn the ball valve, from manual to automatic and back, several times.

 This helps to seat the diaphragm.

6. If there are no leaks, regulate the air back to 0 PSI and remove the plug (11).
7. Make sure no air is leaking from the outlet port.
8. If all tests pass, reattach to the machine.



If air leaks from weep hole, the diaphragm is punctured; a new one needs to be installed.




If air leaks from the diaphragm flange, check the screw torque.

If air still leaks, disassemble/clean the flange and reassemble.

If air leaks from the outlet port when the plug is removed, disassemble and replace items 7 and 8.

The air-piloted, pressure-balancing glue regulator is used with Valco Cincinnati's variable-speed flow controls. The regulator relieves glue pressure during production stops to prevent pattern flooding as production resumes.


The air pressure-to-glue pressure ratio is approximately 3:1. A 1:1, 4:1 & 6:1 ratio assembly is also available. The assemblies include a three-way shutoff valve and air pressure regulator that allow operators to bypass the flow control for system purge and testing.




Pressure-Balancing Glue Regulator

for use with variable-speed
flow controls (3:1 ratio)

DS070





Sous pression (machine en marche)



Aucune pression (machine arrêtée)

When used with EPC, the glue pressure decreases as the machine speed decreases. When the machine is stopped, the glue pressure is relieved from the hose connected to the valve. If the valve needs to be purged or fired while the machine is stopped, air must be supplied to the dome of the regulator by a separate air line.



Bowl Assembly (see drawing above)

Bowl assembly, NPT	593xx411
Bowl assembly, BSPP	593xx410
1 Bottom plug - knurled	593xx297
2 O-ring	745xx080
3 Spring	593xx055
4 Ball support	593xx054
5 Ball, ceramic 3/8"	593xx053
6 Ball seat modification	593xx130
7A Regulator housing, NPT	593xx350
7B Regulator housing, BSPP	593xx351
8 Activator pin	593xx262
9A Socket head pipe plug 1/8 NPT	799xx039
9B Plug, 1/8 BSPP	799xx690

Glue Regulator Assemblies (see drawing on front)

Glue regulator, 3:1 ratio, 0-300 psi, NPT	593xx442
Glue regulator, 3:1 ratio, 0-25 bar, BSPP	593xx443
Glue regulator, 3:1 ratio, Martin	593xx494
1A Bowl Assy. Imp. Bal. Reg.	593xx411
1B Bowl Assy. Metric	593xx410
2A Gauge and Protector Assy. 0-300 psi	593xx112
2B Gauge, Pressure	786xx110
3 Plate, Adapter Flange	593xx444
4 Cylinder, Upper Air	593xx445
5 Cap, Air Cylinder	593xx446
6 Piston, Upper 3:1 Bal Reg	593xx447
7 Cylinder, Lower Fluid	593xx448
8 Piston, Lower 3:1 Bal Reg	593xx449
9 Quad Ring	746xx122
10 Rolling Diaphragm, Mod	746xx114
11 3-Way Ball Valve	704xx745
12 Regulator, Air	594xx114
13 Gauge 960LP	786xx001
14A Elbow-90, 1/4 NPT x 1/4 Tube	799xx169
14B Elbow-90, 1/4 NPT x 5/16 Tube	799xx821
14C Elbow, 1/4 NPT x 5/16 Tube	799xx821
15A Male Connector 1/4" x 1/4 MNPT	799xx723
15B Fitting, 1/4 NPT x 5/16 Tube	797xx395
15C Fitting, 1/4 NPT x 5/16 Tube	797xx395
16 Long Nipple 1/4 x 2 Lg.	797xx089
17 Street Elbow-90 F-M 1/4 x 1/4	797xx007
18A Reducer M-M 3/8 x 1/8	792xx330
18B Coupling, 1/4 NPT-F x 1/8 BSPP-M	792xx137
19 Bracket, Mounting	593xx450
20 O-ring	745xx144
21 Label, Prop Bal Reg	781xx817
22 Screw, 55mm	784xx886
23 Screw, 20mm, SS	784xx426
24 Flat Washer, M6	784xx183
25 Locknut, M6, 0801.0205	798xx416
26 Screw, 55mm	784xx649
27 Tape, Adhesive Transfer	781xx818
28 Tubing	755xx007
29 Tee F-F-F 1/4	797xx023
30 Label, Logo	794xx917
32 Screw, 20mm	798xx047
33 O-ring	745xx103
34 Adhesive Transfer Tape	782xx043
37 Washer, copper	793xx470

Rebuild Kit

Rebuild kit for 3:1 regulator assembly, EP	593xx529
Rebuild kit for 3:1 regulator assembly, Viton	593xx453
1 Rolling diaphragm	746xx114
2 Tape, adhesive transfer	781xx821
3 Quad ring	746xx122
4 O-ring	745xx144
5 O-ring*	746xx163
O-ring**	745xx080
6 Spring	593xx055
7 Ball support	593xx054
8 Ball	593xx053
9 Ball seat Assy, epdm seals*	593xx526
Ball Seat Assembly**	593xx130
10 Male quick disconnect	752xx004
11 Bushing reducer 1/2 x 1/4	797xx049
12 Hex head pipe plug 1/2	797xx040
13 O-ring	745xx103
14 Activator pin; regulator	593xx262
15 Instruction sheet 1:1 prop reg	IS0291

*Included in EP kits.

**Included in Viton kits.

Design specifications subject to change without notice.

DS070

3:1 Glue Regulator Data Sheet

5/2019

Valco Cincinnati Incorporated
411 Circle Freeway Drive
Cincinnati, Ohio 45246, USA
TEL: (1) 513-874-6550
FAX: (1) 513-874-3612

Melton S.L.U.
Pol. Industrial Agustinos
calle G, n. 34
31160 Orcosen, Navarra, Spain
TEL: (34) 948-321-580
FAX: (34) 948-326-584

Valco Cincinnati, Ltd.
Unit 7-8
Hortonwood 32
Telford TF1 7YN England
TEL: (44) 1952-677911
FAX: (44) 1952-677945



Valco Cincinnati GmbH
Storkower Strasse 6
D-15749 Gallun, Germany
TEL: (49) 33764 8700
FAX: (49) 33764 87070

Pressure-Balancing Glue Regulator



for use with variable-speed flow controls (1:3 ratio)


The air-piloted, **pressure-balancing glue regulator** is used with Valco Cincinnati's variable-speed flow controls. The regulator relieves glue pressure during production stops to prevent pattern flooding as production resumes.

The air pressure-to-glue pressure ratio is approximately 1:3. A 1:1 ratio assembly is also available. The assemblies include a three-way shutoff valve and air pressure regulator that allow operators to bypass the flow control for system purge and testing.




ASSEMBLE PISTONS INSIDE TUBE FROM OPPOSITE ENDS TO KEEP SEALS FROM BEING DAMAGED BY INSPECTION HOLE.





When used with EPC, the glue pressure decreases as the machine speed decreases. When the machine is stopped, the glue pressure is relieved from the hose connected to the valve. If the valve needs to be purged or fired while the machine is stopped, air must be supplied to the dome of the regulator by a separate air line.



Bowl Assembly (see drawing above)

Bowl assembly, NPT	593xx286
Bowl assembly, BSPP	593xx272
1 Bottom plug	593xx297
2 O-ring	745xx080
3 Spring	593xx055
4 Ball support	593xx054
5 Ball	593xx053
6 Ball seat	593xx130
7 Activator pin	593xx285
8 Regulator housing, NPT	593xx350
Regulator housing, BSPP	593xx351
9 O-ring	745xx398
10 Plug, 1/8 NPT	799xx039
Plug, 1/8 BSPP	793xx520
11 Socket-head cap screw, M5	798xx047
12 Washer	793xx470
13 Spring pin	091xx444

Glue Regulator Assemblies (see drawing on front)

Glue regulator, 1:3 ratio, 0–160 psi, NPT	593xx284
Glue regulator, 1:3 ratio, 0–12 bar, BSPP	593xx283
1 Flange adapter, air cylinder	593xx292
2 O-ring	745xx528
3 Air cylinder	593xx287
4 Piston	593xx291
5 Piston seal	746xx018
6 Flange adapter, fluid cylinder	593xx289
7 Fluid cylinder	593xx288
8 Shaft	791xx309
9 Piston seal	746xx017
10 Flange adapter, regulator	593xx290
11 O-ring	745xx529
12 Bowl assembly, NPT	593xx286
Bowl assembly, BSPP	593xx272
13 Lock nut	798xx416
14 Flat washer	798xx348
15 Tie rod	791xx308
16 Hex-head screw	798xx645
17 Lock washer	784xx024
18 Bracket	581xx832
19 Three-way ball valve	704xx745
20 Elbow, 1/4 x 1/4 NPT	797xx354
Elbow, 1/4 x 8 mm	787xx483
21 Gauge and protector, 0–300 psi	786xx112
Gauge, 25 bar	786xx079
22 Reducer	797xx070
Coupling, 1/4 BSPP-F x 1/8 BSPP-M	797xx459
24 Gauge, 0–60 psi	786xx001
25 Elbow, 1/4 NPT M-F	797xx007
26 Air regulator	594xx114
27 Nipple, 1/4 NPT	797xx089
28 Fitting, 1/4 x 1/4 NPT	799xx162
Fitting, 8 mm x 1/4 UNI	799xx492
29 Female tee, 1/4 NPT (not shown)	797xx023
30 Tubing, 72-in. length (not shown)	755xx007
31 Socket-head cap screw	798xx069

(Items 29 and 30 not included with metric assembly)

Repair Kit

Repair kit for 1:3 regulator assembly	593xx294
O-ring	745xx080
Spring	593xx055
Ball support	593xx054
Ball	593xx053
Ball seat assembly, includes:	593xx364
ball seat, activator pin and spring pin	
O-ring	745xx398
O-ring	745xx528
Piston seal	746xx018
Piston seal	746xx017
O-ring	745xx529
Washer	793xx470

Design specifications subject to change without notice.

DS046 1:3 Glue Regulator Data Sheet November 2001

Valco Cincinnati Incorporated

411 Circle Freeway Drive
Cincinnati, Ohio 45246, USA
TEL: (1) 513-874-6550
FAX: (1) 513-874-3612

Valco Cincinnati Limited


Hortonwood 32
Telford, TF1 7YN, United Kingdom
TEL: (44) 1952-677911
FAX: (44) 1952-677945

Valco Cincinnati GmbH

Storkower Str. 6
15749 Gallun, Germany
TEL: (49) 33764 870-0
FAX: (49) 33764 870-70

3:1 Balancing Proportional Regulator (Old Version)

Disassembly procedure




1. Relieve pressure from air and glue lines.
2. Remove (4) M6 x 55mm HHCS. Remove cap from regulator assembly. Remove (2) M5 x 20mm SHCS. Remove air cylinder assembly.
3. Remove (6) M5 x 55mm SHCS. Remove cylinder adapter plate. Remove fluid cylinder assembly. Be sure the diaphragm is not stuck to bowl assembly.

Repair Kit (EP - 593XX529; Viton - 593XX453)


ITEM	DESCRIPTION	PART NUMBER	EP	VITON	QTY
1	ROLLING DIAPHRAGM	746XX114			1
2	TAPE, ADHESIVE TRANSFER	781XX821			1
3	QUAD RING	746XX122			1
4	O-RING	745XX144			1
5	O-RING	746XX163	x		1
		745XX080		x	1
		593XX539	x		1
9	BALL SEAT ASSEMBLY	593XX538		x	1
		752XX004			1
10	MALE QUICK DISCONNECT	752XX004			1
11	BUSHING REDUCER 1/2 X 1/4	797XX049			1
12	HEX HEAD PIPE PLUG 1/2	797XX040			1
13	O-RING	745XX103			2
14	ACTIVATOR PIN; REGULATOR	593XX262			1
15	INSTRUCTION SHEET 1:1 PROP REG	IS0291			1

Bowl Assembly Repair




Diaphragm Repair


1. Place the diaphragm (Item #1) face down, on a smooth, clean surface.




2. Place the fluid cylinder over the diaphragm, so the diaphragm flange sits in the fluid cylinder groove. Be sure the screw holes in the diaphragm align with the holes in the fluid cylinder.




3. Place a piece of transfer tape on the bottom of the piston. Cut away the excess. Remove release liner from transfer tape.




4. Place the piston, adhesive side down, into the fluid cylinder so the adhesive contacts the diaphragm.




5. Push piston down. Diaphragm will surround piston.



Seal Replacement



Reassembly Procedure



1. Place the fluid cylinder assembly on the bowl assembly.

C  **!!** Be sure the screw holes are aligned.

2. Place the cylinder adapter plate on top of the fluid cylinder.
3. Use a wire brush to clean remains of thread locker from the screw threads.
4. Apply a liberal amount of blue medium strength thread locker (710XX620) to the M5 x 55mm socket-head cap screw threads.

5. Tighten the screws to 30 in lbs.

CAUTION! Over torqueing can damage the diaphragm.




6. Apply Super Lube, food-grade lubricant (782XX557) to the inside of the air cylinder.
7. Place the air cylinder onto the cylinder adapter plate.
8. Use a flat-head screwdriver to prevent the piston from rotating.
9. Insert the M5 x 20mm socket-head cap screws.
10. Tighten the screws to 30 in lbs.

CAUTION! Do not allow the piston to rotate.



11. Place the cap onto the air cylinder.
12. Tighten the M6 x 55mm hex-head cap screws.




Test Procedure



1. Attach items #10, #11, and #12 to the bowl regulator, as shown above.
2. Attach shop air to item #10, and to the manual air-inlet fitting.
3. Use the air regulator to adjust the pressure to 80 psi.
4. Turn the ball valve from manual to automatic several times, to help seat the diaphragm.
 - a. Leave the valve in the manual position.
5. Check for leaks around the diaphragm.
6. If there are no leaks, regulate the air back to 0 psi, and remove item #12 (plug).
7. Check for air leaks around the outlet port.
8. If all tests pass, reattach to the machine.

The air-piloted, pressure-balancing glue regulator is used with Valco Cincinnati's variable-speed flow controls. The regulator relieves glue pressure during production stops to prevent pattern flooding as production resumes.


The air pressure-to-glue pressure ratio is approximately 3:1. A 1:1, 4:1 & 6:1 ratio assembly is also available. The assemblies include a three-way shutoff valve and air pressure regulator that allow operators to bypass the flow control for system purge and testing.




Pressure-Balancing Glue Regulator

for use with variable-speed
flow controls (3:1 ratio)

DS070




Sous pression (machine en marche)



Aucune pression (machine arrêtée)

When used with EPC, the glue pressure decreases as the machine speed decreases. When the machine is stopped, the glue pressure is relieved from the hose connected to the valve. If the valve needs to be purged or fired while the machine is stopped, air must be supplied to the dome of the regulator by a separate air line.



Bowl Assembly (see drawing above)

Bowl Assembly, NPT	593xx411
Bowl Assembly, BSPP	593xx410
1 Bottom Plug	593xx297
2 O-ring	745xx080
6 Ball/Seat Check Cartridge, Viton	593xx538
7A Regulator Housing, NPT	593xx350
7B Regulator Housing, BSPP	593xx351
8 Activator Pin	593xx262
9A Pipe Plug, NPT	799xx039
9B Pipe Plug, BSPP	799xx690

Glue Regulator Assemblies (see drawing on front)

Glue regulator, 3:1 ratio, 0-300 psi, NPT	593xx442
Glue regulator, 3:1 ratio, 0-25 bar, BSPP	593xx443
Glue regulator, 3:1 ratio, Martin	593xx494
1A Bowl Assy. Imp. Bal. Reg.	593xx411
1B Bowl Assy. Metric	593xx410
2A Gauge and Protector Assy. 0-300 psi	786xx112
2B Gauge, Pressure	786xx110
3 Plate, Adapter Flange	593xx444
4 Cylinder, Upper Air	593xx445
5 Cap, Air Cylinder	593xx446
6 Piston, Upper 3:1 Bal Reg	593xx447
7 Cylinder, Lower Fluid	593xx448
8 Piston, Lower 3:1 Bal Reg	593xx449
9 Quad Ring	746xx122
10 Rolling Diaphragm, Mod	746xx114
11 3-Way Ball Valve	704xx745
12 Regulator, Air	594xx114
13 Gauge 960LP	786xx001
14A Elbow-90, 1/4 NPT x 1/4 Tube	799xx169
14B Elbow-90, 1/4 NPT x 5/16 Tube	799xx821
14C Elbow, 1/4 NPT x 5/16 Tube	799xx821
15A Male Connector 1/4 x 1/4 MNPT	799xx723
15B Fitting, 1/4 NPT x 5/16 Tube	797xx395
15C Fitting, 1/4 NPT x 5/16 Tube	797xx395
16 Long Nipple 1/4 x 2 Lg.	797xx089
17 Street Elbow-90 F-M 1/4 x 1/4	797xx007
18A Reducer M-M 3/8 x 1/8	792xx330
18B Coupling, 1/4 NPT-F x 1/8 BSPP-M	792xx137
19 Bracket, Mounting	593xx450
20 O-ring	745xx144
21 Label, Prop Bal Reg	781xx817
22 Screw, 55mm	784xx886
23 Screw, 20mm, SS	784xx426
24 Flat Washer, M6	784xx183
25 Locknut, M6, 0801.0205	798xx416
26 Screw, 55mm	784xx649
27 Tape, Adhesive Transfer	781xx818
28 Tubing	755xx007
29 Tee F-F-F 1/4	797xx023
30 Label, Logo	794xx917
32 Screw, 20mm	798xx047
33 O-ring	745xx103
34 Adhesive Transfer Tape	782xx043
37 Washer, copper	793xx470

Rebuild Kit

Rebuild kit for 3:1 regulator assembly, EP	593xx529
Rebuild kit for 3:1 regulator assembly, Viton	593xx453
1 Rolling diaphragm	746xx114
2 Tape, adhesive transfer	781xx821
3 Quad ring	746xx122
4 O-ring	745xx144
5 O-ring*	746xx163
O-ring**	745xx080
9 Ball/Seat Check Cartridge, epdm seals*	593xx539
Ball/Seat Check Cartridge, Viton**	593xx538
10 Male quick disconnect	752xx004
11 Bushing reducer 1/2 x 1/4	797xx049
12 Hex head pipe plug 1/2	797xx040
13 O-ring	745xx103
14 Activator pin; regulator	593xx262
15 Instruction sheet 1:1 prop reg	IS0291

*Included in EP kits.

**Included in Viton kits.

Design specifications subject to change without notice. ©2020 Valco Cincinnati Inc. All Rights Reserved. **DS070** 3:1 Glue Regulator Data Sheet 9/2020

Valco Cincinnati Incorporated
411 Circle Freeway Drive
Cincinnati, Ohio 45246, USA
TEL: (1) 513-874-6550
FAX: (1) 513-874-3612


Melton S.L.U.
Pol. Industrial Agustinos
calle G, n. 34
31160 Orcoyen, Navarra, Spain
TEL: (34) 948-321-580
FAX: (34) 948-326-584

Valco Cincinnati, Ltd.
Unit 7-8
Hortonwood 32
Telford TF1 7YN England
TEL: (44) 1952-677911
FAX: (44) 1952-677945

Valco Cincinnati GmbH
Bonnerstrasse 349
40589 Dusseldorf-Benrath,
Germany
Tel: +49 211 984 798-0
Fax: +49 211 984 798-20

Valco Melton France
Technoparc des Hautes Faventines
32 Rue Jean Bertin
26000 Valence
Tel: +33 (0)4 75 78 13 73
Fax: +33 (0)4 75 55 74 20

3:1 Balancing Proportional Regulator (New Version)




1. Relieve pressure from the air and glue lines.
2. Remove the (4) M6 x 55mm hex-head cap screws.
3. Remove the cap from the regulator assembly.
4. Remove the (2) M5 x 20mm socket-head cap screws.

5. Remove the air cylinder assembly.
6. Remove the (6) M5 x 60mm socket-head cap screws.
7. Remove the cylinder adapter plate.
8. Remove the fluid cylinder assembly and bowl adapter plate.

Repair Kit (EP - 593XX528; Viton - 593XX523)


ITEM	DESCRIPTION	PART NUMBER	EP	VITON	QTY
1	DIAPHRAGM, ROLLING	746XX155			1
2	TAPE, ADHESIVE TRANSFER	781XX821			1
3	RING QUAD 3.237" NITRILE	746XX285			2
4	O-RING	745XX307			1
5	O-RING	746XX163	x		1
		745XX080		x	1
9	BALL SEAT ASSEMBLY	593XX539	x		1
		593XX538		x	1
10	MALE QUICK DISCONNECT	752XX004			1
11	BUSHING REDUCER 1/2 X 1/4	797XX049			1
12	HEX HEAD PIPE PLUG 1/2	797XX040			1
13	O-RING	745XX142			1
14	O-RING	746XX162	x		1
		745XX398		x	1
15	ACTIVATOR PIN; REGULATOR	593XX262			1
16	INSTRUCTION SHEET 1:1 PROP REG	IS0291			1
17	FIXTURE - PISTON ALIGNMENT	593XX524			1

Bowl Assembly Repair




Diaphragm Repair


1. Place the diaphragm (Item #1) face down on a smooth, clean surface.




2. Place the fluid cylinder with the dowel pins over the diaphragm, so that the diaphragm sits in the fluid cylinder groove.




3. Place the alignment fixture (Item #17) over the dowel pins.




4. Place a piece of transfer tape on the bottom of the piston.




5. Cut away the excess.
6. Remove the release liner from the transfer tape.
7. Place the piston, adhesive side down, into the fluid cylinder, so the adhesive contacts the diaphragm.




8. Push the piston down. The diaphragm will surround the piston.



Seal Replacement



Reassembly Procedure



1. Place the bowl adapter plate into the bowl assembly.
2. Place the fluid cylinder assembly on top of bowl adapter plate.

CAUTION! Make sure the screw holes are aligned.



3. Place the cylinder adapter plate on top of the fluid cylinder assembly.


4. Install the (6) M5 x 60mm socket-head cap screws.
5. Apply Super Lube, food grade lubricant (782XX557) to the inside of the air cylinder.
6. Place the air cylinder onto the cylinder adapter plate.
7. Insert the air piston into the air cylinder.
8. Use a flat-head screwdriver to prevent the piston from rotating.
9. Insert the (2) M5 x 20mm socket-head cap screws.
10. Tighten the screws to 30 in-lbs.



CAUTION! Do not allow piston to rotate.

11. Place the cap onto the air cylinder.
12. Tighten the (4) M6 x 55mm hex-head cap screws.


Test Procedure



1. Attach the test fittings (items #10, #11, and #12) to the bowl regulator, as shown above.
2. Attach shop air to item #10, and to the manual air-inlet fitting.
3. Use the air regulator to adjust the pressure to 60 psi.
4. Turn the ball valve from manual to automatic several times, to help seat the diaphragm.
 - a. Leave the valve in the manual position.
5. Check for leaks around the diaphragm.
6. If there are no leaks, regulate the air back to 0 psi, and remove item #12 (plug).
7. Check for air leaks around the outlet port, to test for ball check seal leaks.
8. If all tests pass, reattach to the machine.

4:1 Balancing Proportional Regulator Repair

Disassembly Procedure



1. Relieve pressure from the air and glue lines.
2. Remove the (4) M6 x 55mm hex-head cap screws.
3. Remove the cap from the regulator assembly.
4. Remove the (2) M5 x 20mm socket-head cap screws.

5. Remove the air cylinder assembly.
6. Remove the (6) M5 x 55mm socket-head cap screws.
7. Remove the cylinder adapter plate.
8. Remove the fluid cylinder assembly and the cylinder adapter plate.


CAUTION!

Make sure the diaphragm is not stuck to the bowl assembly.

Repair Kit (593XX476)


ITEM	DESCRIPTION	PART NUMBER	QTY
1	ROLLING DIAPHRAGM	746XX155	1
2	ADHESIVE TRANSFER TAPE	781XX821	2"
3	QUAD RING	746XX122	2
4	O-RING	745XX144	1
5	O-RING	745XX080	1
9	BALL SEAT ASSEMBLY	593XX538	1
10	MALE QUICK DISCONNECT	752XX004	1
11	BUSHING M-F 1/2 X 1/4	797XX049	1
12	HEX HEAD PIPE PLUG 1/2	797XX040	1
13	O-RING	745XX103	2
14	O-RING	745XX398	1
15	ACTUATOR PIN	593XX262	1
16	INSTRUCTION SHEET	IS0291	1

Bowl Assembly Repair




Diaphragm Repair


1. Place the diaphragm (Item #1) face down on smooth, clean surface.




2. Place the fluid cylinder over the diaphragm, so the diaphragm flange sits in the fluid cylinder groove.




3. Place a piece of transfer tape on the bottom of the piston.
4. Cut away the excess.
5. Remove the release liner from the transfer tape.




6. Place the piston, adhesive side down, into the fluid cylinder, so the adhesive contacts the diaphragm.




7. Push the piston down. The diaphragm will surround the piston.



Seal Replacement



Reassembly Procedure



1. Place the bowl adapter plate into the bowl assembly.
2. Place the fluid cylinder assembly, on top of bowl adapter plate.

CAUTION! Be sure the screw holes are aligned.



3. Place the cylinder adapter plate on top of the fluid cylinder assembly.
4. Install the (6) M5 x 60mm socket-head cap screws.
5. Apply Super Lube, food grade lubricant (782XX557) to the inside of the air cylinder.


6. Place the air cylinder onto the adapter plate.
7. Insert the air piston into the air cylinder.
8. Use a flat-head screwdriver to prevent the piston from rotating.
9. Insert the (2) M5 x 20mm socket-head cap screws.
10. Tighten the screws to 30 in-lbs.

CAUTION! Do not allow the piston to rotate.



11. Place the cap onto the air cylinder.
 12. Tighten the (4) M6 x 55mm hex-head cap screws.
-

Test Procedure






1. Attach items #6, #7 and #8 to the bowl regulator, as shown above.
2. Attach shop air to item #6, and to the manual air inlet fitting.
3. Use the air regulator to adjust the pressure to 60 psi.

4. Turn the ball valve from manual to automatic several times, to help seat the diaphragm.
5. Leave the valve in the manual position.
6. Check for leaks around the diaphragm.
7. If there are no leaks, regulate the air back to 0 psi, and remove item #8 (plug).
8. Check for air leaks around the outlet port.
9. If all tests pass, reattach to the machine.

The air-piloted, **pressure-balancing glue regulator** is used with Valco Cincinnati's variable-speed flow controls. The regulator relieves glue pressure during production stops to prevent pattern flooding as production resumes. The air pressure-to-glue pressure ratio is approximately 6:1. A 1:1 ratio and 3:1 assemblies are also available.

The assemblies include a three-way shutoff valve and air pressure regulator that allow operators to bypass the flow control for system purge and testing.



Pressure-Balancing Glue Regulator

for use with variable-speed flow controls

DS094




Under Pressure (Machine Running)



No Pressure (Machine Stopped)

When used with EPC, the glue pressure decreases as the machine speed decreases. When the machine is stopped, the glue pressure is relieved from the hose connected to the valve. If the valve needs to be purged or fired while the machine is stopped, air must be supplied to the dome of the regulator by a separate air line.



Bowl Assembly (see drawing above)

Bowl Assembly, NPT	593xx411
Bowl Assembly, BSPP	593xx410
1 Bottom Plug - Knurled	593xx297
2 O-ring	745xx080
6 Ball/Seat check cartridg, Viton	593xx538
7A Regulator Housing, NPT	593xx350
7B Regulator Housing, BSPP	593xx351
8 Activator Pin	593xx262
9A Socket Head Pipe Plug 1/8 NPT	799xx039
9B Plug, 1/8 BSPP	799xx690
10 Washer, Copper	793xx470

Glue Regulator Assemblies (see drawing on front)

Glue Regulator, 6:1 ratio, NPT	593xx504
Glue Regulator, 6:1 ratio, BSPP Metric	593xx505
1A Bowl Assy, 1:1 Imp, Bal Reg	593xx411
1B Bowl Assy, Metric	593xx410
2A Gauge and Protector Assy.	786xx083
2B Gauge, HP	786xx082
3 Flange Adapter, Fluid Cylinder	593xx503
4 Air Cylinder	593xx506
5 Cap, Air Cylinder	593xx507
6 Piston, Upper	593xx508
7 Cylinder, Lower Fluid Bonnet	593xx510
8 Piston, Lower	593xx514
9 Quad Ring	746xx246
10 Rolling Diaphragm	746xx155
11 3-way Ball Valve	704xx745
12 Regulator	594xx114
13 Gauge 960LP	786xx001
14 Elbow 90, 1/4 NPT X 5/16 Tube	799xx821
16 Nipple, 1/4 NPT	797xx089
17 Street Elbow 90 F-M 1/4 X 1/4	797xx007
18A Reducer M-M 3/8 X 1/8	792xx330
18B Adapter 1/4 NPT-F X 1/8 BSPP-M	792xx137
19 Mounting Bracket	593xx509
20 O-ring	746xx214
21 Label	781xx817
22 Screw, M6 X 65mm	884xx346
23 Screw, M6 X 20mm	784xx426
24 Flat Washer M6	784xx183
25 Hex Nut M6	798xx416
26 Screw, M5 X 60mm	884xx545
27 Adhesive Transfer Tape	781xx818
28 8mm Tubing	755xx528
30 Label, Logo	794xx917
31 Data Sheet, Bal Reg 6:1 Air	DS094
32 Screw M5 X 20mm	798xx047
33 O-ring	745xx142
35 Plate, Adapter Flange	593xx475
36 O-ring	745xx398
38 Male Elbow, 5/16I x 1/4NPT	799xx821
39 Pin,Dowel-6MM x 20MM	784xx635
40 Label Stock, silver	781xx780
41 8mm "Y" Fitting	799xx678
42 Tube End Expander	799xx478

Rebuild Kit

Rebuild Kit for 6:1 Regulator Assembly, EP	593xx527
Rebuild Kit for 6:1 Regulator Assembly, Viton	593xx511
1 Diaphragm, rolling	746xx155
2 Tape, adhesive transfer	781xx821
3 Quad ring	746xx215
4 O-ring	746xx214
5 O-ring*	746xx163
O-ring**	745xx080
9 Ball seat assy, epdm seals*	593xx526
Ball/Seat check cartridg, Viton**	593xx538
10 Male quick disconnect	752xx004
11 Bushing reducer 1/2 x 1/4	797xx049
12 Hex head pipe plug 1/2	797xx040
13 O-ring*	745xx142
O-ring**	745xx103
14 O-ring*	746xx162
O-ring**	745xx398
15 Activator pin; regulator	593xx262
16 Instruction sheet 1:1 prop reg	IS0291
17 Fixture - piston alignment	593xx524

*Included in EP kits.

**Included in Viton kits.

Design specifications subject to change without notice. ©2020 Valco Cincinnati Inc. All Rights Reserved. DS094 Pressure-Balancing Glue Regulator 9/2020

Valco Cincinnati Incorporated
411 Circle Freeway Drive
Cincinnati, Ohio 45246, USA
TEL: (1) 513-874-6550
FAX: (1) 513-874-3612

Melton S.L.U.
Pol. Industrial Agustinos
calle G, n. 34
31160 Orcoyen, Navarra, Spain
TEL: (34) 948-321-580
FAX: (34) 948-326-584


Valco Cincinnati, Ltd.
Unit 7-8
Hortonwood 32
Telford TF1 7YN England
TEL: (44) 1952-677911
FAX: (44) 1952-677945

Valco Cincinnati GmbH
Bonnerstrasse 349
40589 Dusseldorf-Benrath,
Germany
Tel: +49 211 984 798-0
Fax: +49 211 984 798-20

Valco Melton France
Technoparc des Hautes Faventines
32 Rue Jean Bertin
26000 Valence
Tel: +33 (0)4 75 78 13 73
Fax: +33 (0)4 75 55 74 20

6:1 Balancing Proportional Regulator Repair

Disassembly procedure




1. Relieve pressure from the air and glue lines.
2. Remove the (4) M6 x 55mm hex-head cap screws.
3. Remove the cap from the regulator assembly.
4. Remove the (2) M5 x 20mm socket-head cap screws.

5. Remove the air cylinder assembly.
6. Remove the (6) M5 x 60mm socket-head cap screws.
7. Remove the cylinder adapter plate.
8. Remove the fluid cylinder assembly and bowl adapter plate.

Repair Kit (EP - 593XX527; Viton - 593XX511)


ITEM	DESCRIPTION	PART NUMBER	EP	VITON	QTY
1	DIAPHRAGM, ROLLING	746XX155			1
2	TAPE, ADHESIVE TRANSFER	781XX821			1
3	QUAD RING	746XX215			2
4	O-RING	746XX214			1
5	O-RING	746XX163	x		1
		745XX080		x	1
9	BALL SEAT ASSEMBLY	593XX539	x		1
		593XX538		x	1
10	MALE QUICK DISCONNECT	752XX004			1
11	BUSHING REDUCER 1/2 X 1/4	797XX049			1
12	HEX HEAD PIPE PLUG 1/2	797XX040			1
13	O-RING	745XX142	x		1
		745XX103		x	1
14	O-RING	746XX162	x		1
		745XX398		x	1
15	ACTIVATOR PIN; REGULATOR	593XX262			1
16	INSTRUCTION SHEET 1:1 PROP REG	IS0291			1
17	FIXTURE - PISTON ALIGNMENT	593XX524			1

Bowl Assembly Repair




Diaphragm Repair


1. Place the diaphragm (Item #1) face down on a smooth, clean surface.




2. Place the fluid cylinder over the diaphragm, so the diaphragm flange sits in the fluid cylinder groove.




3. Place the alignment fixture (Item #17) over the dowel pins.




4. Place a piece of transfer tape on the bottom of the piston.




5. Cut away the excess.
6. Remove the release liner from the transfer tape.
7. Place the piston, adhesive side down, into the fluid cylinder, so the adhesive contacts the diaphragm.




8. Push the piston down. The diaphragm will surround the piston.



Seal Replacement



Reassembly Procedure



1. Place the bowl adapter plate into the bowl assembly.
2. Place the fluid cylinder assembly on top of bowl adapter plate.

CAUTION! Make sure the screw holes are aligned.



3. Place the cylinder adapter plate on top of the fluid cylinder assembly.
4. Reassembly Procedure1. Place the bowl adapter plate into the bowl assembly.

5. Place the fluid cylinder assembly on top of bowl adapter plate.

CAUTION! Make sure the screw holes are aligned.




6. Place the cylinder adapter plate on top of the fluid cylinder assembly.
7. Install the (6) M5 x 60mm socket-head cap screws.
8. Apply Super Lube, food grade lubricant (782XX557) to the inside of the air cylinder.
9. Place the air cylinder onto the cylinder adapter plate.
10. Insert the air piston into the air cylinder.
11. Use a flat-head screwdriver to prevent the piston from rotating.
12. Insert the (2) M5 x 20mm socket-head cap screws.
13. Tighten the screws to 30 in-lbs.

CAUTION! Do not allow piston to rotate.



14. Place the cap onto the air cylinder.
15. Tighten the (4) M6 x 55mm hex-head cap screws.

Test Procedure



1. Attach the test fittings (items #10, #11, and #12) to the bowl regulator, as shown above.
2. Attach shop air to item #10, and to the manual air-inlet fitting.
3. Use the air regulator to adjust the pressure to 60 psi.
4. Turn the ball valve from manual to automatic several times, to help seat the diaphragm.
 - a. Leave the valve in the manual position.
5. Check for leaks around the diaphragm.
6. If there are no leaks, regulate the air back to 0 psi, and remove item #12 (plug).
7. Check for air leaks around the outlet port, to test for ball check seal leaks.
8. If all tests pass, reattach to the machine.