




540BR & 540EC CONTACT/NON-CONTACT VALVES



The 540BR valve assemblies are available for contact gluing designed for use with the BoardRunner contact applicator heads, includes a PNP barrel scanner and bracket assembly for mounting to 16-30 mm square bar. Applicator head sold separately

540EC valves are designed for use with contact or non-contact nozzle assemblies. As above, the assembly includes a PNP barrel scanner and bracket assembly for mounting to 16-30 mm square bar. Specify gluing only or inspection ready - designed to accept the AS302 glue sensor. Nozzles sold separately.



NOTE: See SPECIALTY FOLDER GLUER SALES GUIDE for complete system details using the 540BR and 540EC valves.

The 540BR series valves are solenoid operated for precise glue patterns at high machine speeds. The male swivel seat adapter allows for the mounting of BoardRunner Applicator Head. The valve features a carbide tipped plunger assembly and no dynamic seals for long life. The 540BR can also be converted to a 540EC for non-contact applications. The 540BRR version offers an adjustable stroke for more flexible pattern control. The 540EC can also be converted to a 540BR for contact applications. The 540ECR version offers an adjustable stroke for more flexible pattern control.

| 540 Series Valves | |
|-------------------|--------------|
| Technical Data | |
| Coil | 5.3ohms |
| Valve Width | 25mm |
| Fluid Pressure | 400 psi |
| Viscosity | 300-2500 cps |
| Hold Voltage | 6VDC |



540BR & 540EC CONTACT/NON-CONTACT VALVES

Valve Mounting Brackets - 540 Series

- Following bracket assemblies do not include the glue valve

| 540 Series Mounting Brackets | | |
|-------------------------------|----------|--|
| | PN | DESCRIPTION |
| <p>579xx421 579xx427</p> | 579xx421 | Mounting bracket, non-contact valve (ordered separately), with scanner bracket and scanner |
| | 579xx743 | Mounting bracket, non-contact valve (ordered separately), with out scanner bracket and scanner |
| | 579xx427 | Mounting bracket, contact valve (ordered separately), with scanner bracket and scanner |
| | 579xx512 | Mounting bracket, contact valve (ordered separately), with out scanner bracket and scanner |


- Following bracket clamp for use on Post machines

| 540 Series Mounting Brackets | | |
|------------------------------|----------|--------------------------------------|
| | PN | DESCRIPTION |
| | 579xx846 | Bracket clamp adapter, Post machines |



540BR & 540EC CONTACT/NON-CONTACT VALVES

Complete Gluing Station 540EC Series Valve, Inspection Ready


| | PN | DESCRIPTION |
|---|----------|--|
|  | 579xx517 | 540EC valve assembly, inspection ready, non-contact, for stainless-steel HACK. AS302 sensor and nozzle ordered separately. |
| | | Above assembly includes: 707xx469 540EC valve assembly 280xx288 Scanner |

NOTE: See SPECIALTY FOLDER GLUER SALES GUIDE for complete system details using the 540BR and 540EC valves.



540BR & 540EC CONTACT/NON-CONTACT VALVES

540BRT/BRR Contact Glue Valves



The 540BR series valves are solenoid operated for precise glue patterns at high machine speeds. The male swivel seat adapter allows for the mounting of BoardRunner Applicator Head. The valve features a carbide tipped plunger assembly and no dynamic seals for long life.

The 540BR can also be converted to a 540EC for non-contact applications. The 540BRR version offers an adjustable stroke for more flexible pattern control.

NOTE: Viton is standard seal material. EP seals are available as an option for adhesive formulas that react with the Viton (causing them to swell).

| 540BRT/BRR Contact Glue Valves | | | |
|--|-----------|----------|---|
| | STD VITON | EP SEALS | DESCRIPTION TITLE |
| <p>707xx468 shown with 579xx427 mounting bracket, 280xx288 scanner and BoardRunner applicator head</p> | 707xx467 | 707xx651 | 540BRT valve, non-adjustable stroke |
| | 707xx468 | 707xx653 | 540BRR valve, adjustable stroke |
| | 707xx447 | 707xx631 | Maintenance Kit 540EC/BR. Maintenance kit includes lithium grease, flushing adapter nozzle cleaning drills, cleaning brush, o'rings and valve spring. |

NOTE: BoardRunner applicator head ordered separately.




540BR & 540EC CONTACT/NON-CONTACT VALVES

| 540BR/T Components | | | | |
|---|------|-----------|----------|--|
| | ITEM | STD VITON | EP SEALS | DESCRIPTION |
| | 1 | 799xx658 | 707xx607 | Fitting Female Swivel |
| | 2 | 707xx504 | 707xx615 | JIC Coupler |
| | 3 | 745xx339 | 746xx119 | O-ring (included w/items 1,2) |
| | 4 | 707xx472 | 707xx608 | Back Stop Assembly Adjustable |
| | 5 | 712xx014 | 712xx015 | Back stop assembly, non-adjustable |
| | 6 | 745xx340 | 746xx089 | O-ring (included w/items 4,5) |
| | 7 | 707xx477 | 707xx477 | Valve Sub Assembly |
| | 8 | 798xx049 | 798xx049 | Socket Head Cap Screw |
| | 9 | 783xx042 | 783xx042 | Spring |
| | 10 | 707xx482 | 707xx482 | Plunger 4mm Ball |
| | 11 | 745xx007 | 746xx170 | O'ring (included w/item 14) |
| | 12 | 746xx069 | 746xx069 | O-ring (included w/item 13) |
| | 13 | 707xx462 | 707xx462 | Seat Assembly |
| | 14 | 707xx459 | 707xx611 | Applicator Head Adapter Assembly, includes Items 11,12 &13 |
| Repair kits, include O-rings spring and mounting screws | | | | |
| | | 712xx012 | 712xx013 | Repair kit, 540 series |



540BR & 540EC CONTACT/NON-CONTACT VALVES

540ECR/ECT Valves



The 540ECR/ECT series valves are solenoid operated for precise glue patterns at high machine speeds. The valve features a carbide tipped plunger assembly and no dynamic seals for long life.

The 540EC can also be converted to a 540BR for contact applications. The 540ECR version offers an adjustable stroke for more flexible pattern control.

NOTE: Viton is standard seal material. EP seals are available as an option for adhesive formulas that react with the Viton (causing them to swell).


540ECR/ECT Non-Contact Glue Valves

| | STD VITON | EP SEALS | DESCRIPTION TITLE |
|---|-----------|----------|---|
| <p>707xx469 shown with 579xx421 mounting bracket, 280xx288 scanner and non-contact nozzle</p> | 707xx466 | 707xx650 | 540 ECT valve, non-adjustable stroke |
| | 707xx469 | 707xx652 | 540 ECR valve, adjustable stroke |
| | 707xx447 | 707xx631 | Maintenance Kit 540EC/BR. Maintenance kit includes lithium grease, flushing adapter nozzle cleaning drills, cleaning brush, o'rings and valve spring. |



540BR & 540EC CONTACT/NON-CONTACT VALVES

540ECR/ECT Components





| ITEM | STD VITON | EP SEALS | DESCRIPTION |
|--|-----------|----------|--|
| 1 | 799xx658 | 707xx607 | Fitting Female Swivel |
| 2 | 707xx504 | 707xx615 | JIC Coupler |
| 3 | 745xx339 | 746xx119 | O-ring, included w/items 1, 2 |
| 4 | 707xx472 | 707xx608 | Back Stop Assembly Adjustable |
| 5 | 712xx014 | 712xx015 | Back stop assembly, non-adjustable |
| 6 | 745xx340 | 746xx089 | O-ring, included w/items 4, 5 |
| 7 | 707xx477 | 707xx477 | Valve Sub Assembly |
| 8 | 798xx049 | 798xx049 | Socket Head Cap Screw |
| 9 | 783xx042 | 783xx042 | Spring |
| 10 | 707xx482 | 707xx482 | Plunger 4mm Ball |
| 11 | 745xx007 | 746xx170 | O'ring, included w/item 14 |
| 12 | 746xx069 | 746xx069 | O'ring, included w/item 14 |
| 13 | 707xx462 | 707xx462 | Seat Assembly |
| 14 | 707xx461 | 707xx612 | Nozzle Adapter Assembly. Includes Items 11, 12, 13 & 15 |
| 15 | 707xx445 | 707xx445 | Retaining Nut |
| Repair kits, include O-rings, spring and mounting screws | | | |
| | 712xx012 | 712xx013 | Repair kit, includes O-rings, spring and mounting screws |



540BR & 540EC CONTACT/NON-CONTACT VALVES





540EC Valve - Nozzle Options

| 540EC Valve - Nozzle Options | |
|---|--|
| | PN DESCRIPTION TITLE |
|  707xx489 | Single Vein Non-Contact Nozzles |
| | 707xx489 Nozzle, 0.012 (.3mm) |
| | 707xx488 Nozzle, 0.016 (.4mm) |
| | 707xx487 Nozzle, 0.020 (.5mm) |
| | 707xx486 Nozzle, 0.024 (.6mm) |
| 707xx485 Nozzle, 0.028 (.7mm) | |
|  707xx458  707xx455  707xx497 | Multi-Vein Non-Contact Nozzles |
| | 707xx881 Nozzle, 2 vein .015(0.4mm), .250 spacing |
| | 707xx882 Nozzle, 2 vein .020(0.5mm), .250 spacing |
| | 707xx883 Nozzle, 2 vein .024(0.6mm), .250 spacing |
| | 707xx884 Nozzle, 2 vein .031(0.8mm), .250 spacing |
| | 707xx885 Nozzle, 3 vein .015(0.4mm), .250 spacing |
| | 707xx886 Nozzle, 3 vein .020(0.5mm), .250 spacing |
| | 707xx887 Nozzle, 3 vein .024(0.6mm), .250 spacing |
| | 707xx888 Nozzle, 3 vein .031(0.8mm), .250 spacing |
| | 707xx889 Nozzle, 4 vein .020(0.5mm), .250 spacing |
| | 707xx890 Nozzle, 4 vein .024(0.6mm), .250 spacing |
| | 707xx891 Nozzle, 4 vein .031(0.8mm), .250 spacing |
| | 707xx892 Nozzle, 5 Vein 0.6mm diameter 0.125 centers |
| | 707xx893 Nozzle, 7 Vein 0.6mm diameter 0.125 centers |
| 707xx449 Old-style nozzle replacement nozzle insert - Bulletin116 | |
| Contact Nozzles | |
| 707xx498 Contact nozzle assy, 0.39 (1mm), single vein | |
| 707xx497 Contact nozzle assy, 0.39 (1mm), 0.25(6.35mm) centers two vein | |
| 707xx496 Contact nozzle assy, 0.39 (1mm) 0.25 (6.35mm) centers three vein | |
| 707xx495 Contact nozzle assy, 0.39 (1mm) 0.236 (6mm) centers 4 vein | |



540BR & 540EC CONTACT/NON-CONTACT VALVES

Non-Contact / Contact Conversion Kits

| Conversion Kits Contact/Non-Contact 540 Valve | | PN | DESCRIPTION |
|---|----------|--|-------------|
|  579xx520  707xx461 | 707xx299 | Conversion kit, contact to non-contact 540 valve, includes 707xx461 Nozzle adapter assembly 579xx520 Guide foot assembly | |
|  579xx429  707xx459 | 707xx297 | Conversion kit, non-contact to contact 540 valve, includes 707xx459 Applicator head adapter assembly 579xx429 Guide foot assembly | |
|  579xx422 | 707xx298 | Conversion kit, J&L specific, contact to non-contact 540 valve, includes 707xx461 Nozzle adapter assembly 579xx422 Guide foot assembly | |
|  579xx828 | 579xx878 | Guide foot assembly, for use with applicator heads wider than 5-vein | |